

1. Print this page
2. Measure 170mm line. Adjust printer settings until the line measures 170mm.
3. Cut out red template and attach to a stiff material such as cardboard or manilla folder.
4. Cut backing material to shape of template.
5. Insert hub snout into wheel then sweep around the inside of the wheel check for clearance.
6. Template must have at least 3mm (.120") clearance to any part of wheel

SUPERMIATA.COM

