

1. Print this page
2. Confirm scale on page is correct with ruler
3. Carefully cut brake schematic from page
4. Attach to piece of single layer cardboard
5. Scribe or mark shape of caliper assembly into cardboard
6. Cut away cardboard so only schematic with backing is remaining. This is your clearance template
7. Place hub snout from template into wheel.
8. Minimum recommended clearance is 3mm / .120"
9. Check clearance again after installing brakes

BX11 brake clearance template

90-05 MX5 Miata

